

## Ignition Starter Switches



4 Position Switch with Momentary Start and Universal Type Die-Cast Housing.

Results 1 - 25 of 29

| Item #     | Item Name                 | Mounting Hole Pattern | Starter/Lockout |
|------------|---------------------------|-----------------------|-----------------|
| 31-103     | Ignition Starter Switches | 2                     | N               |
| 31-104     | Ignition Starter Switches | 2                     | N               |
| 31-105     | Ignition Starter Switches | 2                     | Y               |
| 31-106     | Ignition Starter Switches | 2                     | Y               |
| 31-109     | Ignition Starter Switches | 1                     | N               |
| 31-110     | Ignition Starter Switches | 1                     | N               |
| 31-111     | Ignition Starter Switches | 1                     | N               |
| 31-131     | Ignition Starter Switches | 1                     | N               |
| 31-159     | Ignition Starter Switches | 3                     | N               |
| 31-178     | Ignition Starter Switches | 5                     | N               |
| 31-180     | Ignition Starter Switches | 5                     | N               |
| 31-190     | Ignition Starter Switches | 4                     | N               |
| 31-196     | Ignition Starter Switches | 4                     | N               |
| 31-233     | Ignition Starter Switches | 2                     | Y               |
| 31-292     | Ignition Starter Switches | 2                     | Y               |
| 31-292-801 | Ignition Starter Switches | 2                     | Y               |
| 31-292-802 | Ignition Starter Switches | 2                     | Y               |
| 31-292-803 | Ignition Starter Switches | 2                     | Y               |
| 31-292-804 | Ignition Starter Switches | 2                     | Y               |
| 31-292-805 | Ignition Starter Switches | 2                     | Y               |
| 31-292-806 | Ignition Starter Switches | 2                     | Y               |
| 31-305     | Ignition Starter Switches | 5                     | Y               |
| 31-607     | Ignition Starter Switches | 2                     | N               |
| 31-608     | Ignition Starter Switches | 2                     | Y               |
| 31-610     | Ignition Starter Switches | 4                     | Y               |

Results 1 - 25 of 29